



WISTERIA LANE® HD (High Density) Laminate / Wood Flooring Underlayment

You won't find a better underlayment with more sound or moisture control...Even if you pay more!

The Wisteria Lane® HD Underlayment Difference:

- Overcomes most sub-floor imperfections
- Waterproof (closed cell construction) No Vapor Barrier Needed
- Comes with pre attached self adhesive tape for joining at the seams
- Use over both concrete and wood sub-floors
- **Use in glue down or nail down installations as a sound and vapor barrier**
- Designed for optimal joint stability and foot comfort
- 98% Memory Retention
- Superior foot traffic sound control
- HIGHEST SOUND RATINGS AVAILABLE IN THE U.S.

Specifications:

IIC Rating	<u>72 db</u>
STC Rating	<u>67 db</u>
Water Resistance	<u>Waterproof (Moisture cannot penetrate closed cell membrane)</u>
Thickness	<u>3mm</u>
Roll Width	<u>3 Ft. 3 6/16 inches (1.0M)</u>
Sq. Ft. per Roll	<u>200 Sq. Ft.</u>

Installation Instructions:

1. Clean sub-floor, removing all debris.
2. Check sub-floor for levelness. Float uneven areas as necessary to 3/16" in a 10' radius.
3. Roll out the first row of Wisteria Lane 3 in 1 HD Underlayment PE (shiny) SIDE DOWN, (shiny side up for radiant heat installation) allowing the underlayment to run up exterior walls 1 to 2 inches.
4. Begin installing your floor. When you are near the edge of the first row of underlayment, roll out the second row.
5. Be sure to align the edges of the first and second rows of underlayment as tightly as possible, but DO NOT overlap.
6. Join the underlayment seam with the self adhesive tape already affixed to the Wisteria Lane 3 in 1 HD Underlayment. Mend any rips, or punctures to the underlayment using a moisture resistant polyethylene tape.
7. Repeat steps until installation is complete.
8. Trim excess underlayment to allow for perimeter molding installation.